Package Contents

L1 Projector

HDMI Cable

3-in-1 AV Cable

Remote Control

Power Cord

Cleaning cloth

Lens Cover

Quick Start Guide

Product Overview

Projector Lens   IR Window

USB Port
AV Port
Headphone Port
HDMI Port

Air Inlet

Power Port
IR

Air Outlet

Buttom Lable

Mount Hole

Manual Focus+
Manual Focus-

Power

Turn on Yaber Projector

Connect Devices

Yaber L1 projector has 4 ports, HDMI port/Headphone Port/AV port/USB port. Please select the correct connecting port to connect your device (PC, Phone, DVD Player, Sound bar, USB, PS4 etc.)

1.iOS Cast (for iOS Devices)

1.Go to "SETTINGS" page – Select the [Settings] menu – Select the [Wi-Fi Setting] menu – Open the Wi-Fi function – Select your home Wi-Fi from the list – Connect the L1 projector to your home Wi-Fi.

Settings

2.Go to "APPS" page – Select "My Apps" row – Find [iOS Cast] App – Press the OK button to enter the [iOS Cast] menu.

3.Select the [Settings] menu on your iOS device – Turn on the [Wi-Fi] function – Connect your iOS device to the same home network as the projector.

4.Open the [Control Center] on your iOS device – Select the [Screen Mirroring] function – Select and connect the iOS Cast receiver named [L1-Cast-XXXX] – your iOS device screen will be displayed on the projection screen after 3 seconds.

Screen Mirroring

Screen Mirroring

Stop Mirroring

Scan and download the PDF user manual

### Where to Get More Help

2.Connect the Devices via the HDMI port

1. Connect your TV stick or laptop to any HDMI port of the projector.
2.Enter the home page to select the corresponding HDMI as the signal source.

3.Miracast (for Android Devices)

1.Go to "APPS" page – Select "My Apps" row – Find [Mira Cast] App – Press the OK button to enter the [Cast] menu.

Miracast
To connect Android Mobile/Pad with Projector Based on WIFI-Display Technology

2.Select the [Settings] menu on your Android device – Select the [Screen mirroring] function – Select your Miracast receiver named [L1-Cast-XXXX] – your Android device screen will be displayed on the projection screen after 3 seconds.

Wireless Projection
Available devices
📶 L1-Cast-XXXX
HELP | CANCEL

Wireless Projection
Available devices
📶 L1-Cast-XXXX
Connected
CANCEL | DISCONNECT

Adjust the Angle and Definition

1.Image Adjustment

If the image is not clear. You can use the manual focus function, and press the focus buttons "F+" and "F-" on the remote control to adjust the focus of the lens, until the image is clear.
Note： If it is still blurry, please try moving projector to the best distance. The best projection distance is 2-3 meters.

Bluetooth Settings

1. Open your Bluetooth device.

2. Go to home page – Select the [⚙] menu – Select the [Bluetooth Setting]menu – Open the Bluetooth function – Select your Bluetooth device – Press the OK button to connect.

Note:
The L1 projector is compatible with the Bluetooth headsets, Bluetooth speakers and Airpods, but not the Bluetooth keyboards or Bluetooth phones.

Yaber

Quick Start Guide
Mini Projector L1 EN